



Self-cleaning sensors for automated continuous slurry viscosity and weight monitoring in-tank

Joe Goodbread, Sunil Kumar, Daniel Brunner, Daniel R.H. Lima, Caroline E. Giacomini

Rheonics

 Winterthur, Switzerland

 Sugar Land, Texas, U.S.A.



Agenda


1. Background
2. Motivation
3. Design Principle
4. Proof of Concept
5. Field Trial
6. Outlook



Background

1. Background

Slurry consistency measurements



1. Background

Current slurry monitoring options

1

Manual measurements



2

Continuous in-tank viscosity and density measurements



1. Background

Problems with existing systems: manual

1

Manual measurements



- Intermittent
- Operator variability
- Time consuming
- Frequent device cleaning
- Samples tested outside of process conditions
- Time delay

1. Background

Problems with existing systems: in-tank




- Many slurries give continuous readings without issue.
- Slurries, by design, adhere to surfaces.
- Deposits formation can distort readings.
- Cleaning schedules/checks for sensor can be required.

1. Background

Problems with existing systems: in-tank

- Cleaning requirements differ by foundry and slurry.
- Observing readings over time is required to find necessary cleaning frequency
- Hurdle towards measurement use in process control



Method for preventing deposition is desired.



Motivation

2. Motivation

Desired outcomes

- Uninterrupted reading
- Built-in cleaning mechanism:
 - Prevent deposit formation
 - Remove deposits after formation
- Reduce maintenance
- Increase shell room operator trust



Is this even possible?

2. Motivation

Deposit-free sensor

Standardize
cleaning
timeline?

Too much variation between slurries

Cleaning
robots?

Not fast enough for some deposits

Non-stick
coatings?

Slurries are abrasive

Self-cleaning?



2. Motivation

Requirements

- Self-cleaning
- Prevents deposition
- Compatible with existing sensor technology
- Does not interfere with measurements
- Does not interfere with tree dipping



Design Principle

3. Design Principle

Inspiration



3. Design Principle


Features



Rheonics SRD sensor



Mount for adjustable length




Built-in Vibrator

- High amplitude
- Low frequency

Proof of Concept

4. Proof of Concept


Validation



- Kitchen mixer with rotating bowl and plow blade
- Ransom & Randolph SuspendaSlurry
- Rheonics SRD for viscosity and density measurements
- Pneumatically-actuated vibrator

4. Proof of Concept


Experimental procedure



- Drum was rotated at a constant speed
- Viscosity and density recorded as a function of time
- Cleaning vibration alternated:
 - 25 minutes off
 - 25 minutes on

4. Proof of Concept

Results



4. Proof of Concept

Manual density check

- Agrees well with conventional density measurement



Field Trial

5. Field Trial


Validation in industrial shell room



- Prime slurry
- Slurry previously known to form deposits on sensor in-tank
- Plant operation continues normally
- Data acquired in parallel from:
 - Efflux cup
 - Rheonics SRD with vibration
- Continuous operation
 - 5 months so far !

5. Field Trial


Results from SRD with vibration



- No cleaning or inspection for period shown
- 1 month of operation
- Vibration run continuously
- Density remains constant

5. Field Trial

Results from SRD with vibration with efflux cup



Outlook

6. Outlook

Requirements fulfilled

- ✓ Self-cleaning
- ✓ Prevents deposition
- ✓ Compatible with existing sensor technology
- ✓ Does not interfere with measurements
- ✓ Does not interfere with tree dipping

6. Outlook

Shell room automation

- Extends application of SRD viscosity and density measurements to **deposit prone slurries**
- Reduces reliance on **manual measurements**
- **Saves cleaning time**
- **Increases trust** of in-tank measurements
- **Reduces measurement reliability** concerns
- Step towards **Industry 4.0**



Questions?

Rheonics GmbH

Winterthur, Switzerland 

Tel: +41 52 511 32 00

Rheonics, Inc.

Texas, U.S.A.

Tel: +1 713 364 5427

Web:

<https://rheonics.com>

Email:

Sales: info@rheonics.com

Support: support@rheonics.com

